



DURAFLAP INSTALL DIRECTIONS FOR FORD F-250/ F-350/ F-450 FRONT DRILLESS MUDFLAPS 1999 to 2007

Included supplies: 4- #8 x 1 1/4" Stainless Steel Black Oxide (SSBO) Screws; 4- #10 (SSBO) Washers; 4- Small U-Clips; 2- (SSBO) 1/4-20 x 1" bolts; 2- (SS) flange nuts; 2-1/4" (SSBO) washers.

NOTE: As you progress with the install, check that the mud flap remains square and plumb to the tire.

Step 1: Remove factory push pins or screws located at points "A and B", (See picture below).

Step 2: If needed, install "U-Clips" to the liner at points A and B. Slide them over the factory holes with the threaded side to the rear, flat side forward.

Step 3: Use the #8 x 1 1/4" screw and washer to install the mud flap (grooved side facing the tire) at Points A and B. Just hand tight for now.

Step 4: Secure the mud flap to the liner at point C with the 1/4-20 x 1" bolt, washer and flange nut. Just hand tight for now.

Step 5: Align the mud flap to be plumb vertically and tighten all screws and or bolts.

Note: Recheck bolts every three months and retighten as necessary.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148

