



DURAFLAP INSTALL DIRECTIONS FOR FORD 2003-2006 EXPEDITION REAR Drill-less MUDDLAPS

Included Supplies: 6 - Aluminum Flat clips; 6 - 1/4-20x1.25; Stainless Steel Black Oxide (SSBO) Bolts; 6- 1/4"(SSBO) washers; 6 - 1/4-20 SS Flange Nuts; 2 - small anodized u-clips; 2 - (SSBO) #8 x1.125 Screws; 2- #10 (SSBO) Small Inner-Diameter Washers

NOTE: As you progress with the install, check for squareness and plumbness of the mudflap to the tire.

- Step 1: Un package your new mudflaps. Smooth side is rear side. If applicable, Stainless Steel weights face rearwards.
- Step 2: Remove factory screws or bolts from fender well lip at point C.
- Step 3: Slide the U-clip over the factory holes (if needed) in the fender well with the threaded protrusion toward the rear of the truck. You may use factory clips if they are already installed.
- Step 4: At points B,C and D. Attach the flat clip to the back (smooth side) of the mud flap with the hex bolt going thru the SS washer, thru the grooved side of the mud flap, then attach the flat clip with the bend facing the mud flap and secure with the supplied flange nut. Leave loose for now.
- Step 5: Place the mudflap with the smooth side to the rear and the textured side to the front inside the fender well. Start the screw thru the washer, the pre-drilled hole in the mudflap at point C and into the factory hole "C" and thru the U-Clip, finger tighten only.
- Step 6: Slip the bottom longer end of the top Flat Clip over the fender well lip, and slightly tighten causing the clip to grip the metal lip at point "A".
- Step 7: Slip the bottom longer end of the top Flat Clip over the fender well lip, and slightly tighten causing the clip to grip the metal lip at point "B".
- Step 8: Slip the bottom longer end of the top Flat Clip over the fender liner, and slightly tighten causing the clip to grip the plastic liner at point "D".
- Step 9: Align the mudflap to be plumb vertically and tighten all screws and bolts.

Note: Recheck bolts and screws every three months and retighten as necessary.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148

