



Directions for Toyota Tundra FRONT Drill-less installation 2022-current

Included hardware: 10- Stainless Steel Black Oxide (SSBO) 14 x 1 slotted hex screws;
10- (SSBO) 1/4" washers

Thread locker is recommended on all screws and bolts.

NOTE: *As you progress with the install, check that the mud flap remains square and plumb to the tire.*

- Step 1: Un-pack your new mud flaps. Smooth side is rear side, grooved side faces the tire, tapered corner is the outside top edge. If applicable, Stainless Steel weights face rearwards.
- Step 2: Remove the factory splash guards if they are in place.
- Step 3: Remove remaining factory screws located at points A and E.
- Step 4: Align the pre-drilled hole in the mud flap with factory hole E and thread the supplied screw through the supplied washer, through the mud flap and into the factory hole. Leave slightly loose.
- Step 5: Repeat step 4 at points A,B,C and D.
- Step 6: Check for proper alignment to the tire, and tighten all screws.

Note: **Recheck every three months and retighten if necessary.**

Add moisture to the mud flaps a couple times a year using furniture polish, leather or vinyl protectant.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148

