



Chevy Colorado 2023-Current Front Install Directions

Included hardware: 4- (#8) x 1.25" screws stainless-steel black oxide (SSBO); 2- (#8) x 1.5" SSBO screws; 6- (#10) SSBO washers; 2 - small u-clips just in case;

2- Flat Clips #10016; 2- 3/4" thick round plastic spacers #

Thread locker is recommended on all non-nylok fasteners

NOTE: *Park on level surface for installation. As you progress with the install, check that the mud flap remains square and plumb to the tire.*

- Step 1:** Remove mud flaps from package. Smooth side faces rear, tapered corner on top is outside top edge. If applicable, Stainless Steel weights face rear.
- Step 2:** Attach the flat clip to the back (smooth) side of the mudflap at Point **A**. Use a #8 x 1.25 (SSBO) screw thru the (SSBO) #10 washer, thru the tire side of the mudflap (side with grooves), into the U-clip. Leave loose for now. See picture on the back.
- Step 3:** Remove the factory screws at points **B** and **C**, being careful not to break the u-clip behind the liner.
- Step 4:** Align the pre-drilled hole in the mud flap with factory hole **C** and use the (#8) x 1.5" screw and with (#10) washer through the mud flap, then the round plastic spacer and into the u-clip at point **C**. Leave slightly loose.
- Step 5:** Secure point **B** with a #8 x 1.25 screw and washer. Leave slightly loose.
- Step 6:** Slide the "FLAT CLIP" under the fender well lip, and tighten causing to grip the fender firmly at Pont **A**.
- Step 7:** Check alignment and tighten all screws and bolts.

Note: Re-check every three months and retighten if necessary.

Add moisture to the mud flaps 2 times a year. Use furniture polish or vinyl treatment.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148



