



Pre-drilled installation 2023 - current GMC 1500 AT4X Rear Mud Flaps

Hardware: 10- #8 x 1 1/4"-stainless steel black oxide (SSBO) screws; 10- #10 (SSBO) washers ;
4- #8 x 7/8" SSBO screws; 2-AL 2020 Chevy Flat Bracket #10028;

Thread locker is recommended for all screws

NOTE: As you progress with the install, check for alignment of the mud flap to the tire.

- Step 1: Un package your new rear mud flaps. Smooth side is rear side, tapered corner on top is outside top edge. If applicable, Stainless Steel weights face towards the rear of the vehicle.
- Step 2: Remove factory screws at points C, D and E, be careful not to break the u-clips.
- Note: The bracket will have stickers on it, D for driver side and P for passenger side.**
- Step 3: Slip the edge of the bracket behind the plastic flare and trim cap. **See picture on for placement. The bracket is a tight fit, and will need to be adjusted to line up the clips in the bracket with the holes in the mud flap. Pre install the flap to make adjustments to the bracket as needed.**
- Step 4: Align the mud flap to points C, D and E. With the longer 1 1/4" screws thru a washers.
- Step 5: Attach the mud flap at points A and B with a 7/8" screw, going thru a washer. We have provided longer screws to be used if needed.
- Step 6: Check alignment for plumb readjust if needed and then tighten all screws.

NOTE: Recheck every three months and retighten bolts if necessary.

Add moisture to your mud flaps at least twice a year using furniture polish or vinyl or leather treatment.

If you have any questions, problems or concerns please phone us at (541) 245-9148

