



## How To Measure for Custom Shifting and Length For Lifted Trucks With Offset Wheels

We will custom shift our drill-less mud flaps to your offset wheels, so they will be centered to your tires. We also make them custom length for your lift.

Custom size or positioning is an additional \$50 per pair on single wheels and \$60-70 per pair on dual wheels.

First you will want to view the install directions. Make sure to choose the correct factory hole to measure from.

**VERY IMPORTANT:** Custom mud flaps are non-returnable, so please measure carefully. We are here to walk you through the measuring to make sure you get the measurements correct.

- 1 - Measure from the factory hole (choose from instructions) to the outside of the tire using a straightedge. (See Pictures below) Factory hole  Measurement
- 2 - Measure from the same factory hole to the ground.
- 3 - Measure the tire width.
- 4 - Now choose if you want 12", 14" or custom width mudflaps.

Example: If your tires are 13" wide, and you are going to use our 14" wide mud flaps; we will add .5" to your measurements this will leave .5" on the inside and outside of the tires. This centers the mud flap to your tire.

- 5 - Now choose how far off the ground you would like your mud flaps.

We do recommend you stay at least 7" off the ground to avoid backing up into curbs or parking guards. You want them to be no more than 10" of the ground to properly protect your vehicle.

Need help? Review the install directions that were sent to you, then call us when you are by your truck and ready to measure. (541) 245-9148

